



Download the most recent application information at  
[www.PullRite.com](http://www.PullRite.com)

## SuperGlide - Short Box 5th Wheel Hitches - 2008

Call 800/443-2307 for additional application information  
 when king pin is located behind front edge of trailer.

	12K SuperGlide	14K and 18K SuperGlide		24K SuperGlide
<p>IMPORTANT: The 14K &amp; 18K SuperGlide Models are available with a choice of mounting systems - a traditional "fixed base rail in the bed system" utilizing Universal "L" Brackets - or, the "totally Removable Base Rail SuperRail system" utilizing vehicle specific Custom Mounting Brackets for stronger, safer, more stable towing platforms.</p>	Hitch Part Number - Requires Mounting Kit Below for Installation	Hitch Part Number - Requires One of the Mounting Kits Below for Installation - Either the removable rail SuperRail Kit - or the fixed bed rail Universal Kit		Hitch Part Number - Requires Mounting Kit Below for Installation
	<b>PullRite #</b>	<b>PullRite #</b>	<b>PullRite #</b>	<b>PullRite #</b>
	<b>3100</b>	<b>4100</b>	<b>4400</b>	<b>3600</b>
				
<p>The 12K SuperGlide features the "totally removable SuperRail system" utilizing the Custom Mounting Brackets. The 24K SuperGlide Model doesn't use base rails, but features a unique "post mount" system - resulting in a completely smooth, clean bed when the hitch is removed.</p>	<b>SuperRail Kit</b>	<b>SuperRail Kit</b>	<b>Universal Rail Kit</b>	<b>SuperRail Kit</b>
	Kit includes removable SuperRails & Posts, Custom Mounting Brackets & Hardware (All 12K Models are Removable Base Rail Design)	Kit includes removable SuperRails & Posts, Custom Mounting Brackets & Hardware	Kit includes bolt to the bed Base Rails, Universal "L" Brackets & Hardware	Kit includes removable Mounting Posts, Custom Mounting Brackets & Hardware (All 24K Models are BaseRailless Designs - NO Rails Required)
<b>Suggested Retail Pricing for Mounting Kits</b>	<b>\$646.00</b>	<b>\$449.00 - \$559.00</b>	<b>\$204.00</b>	<b>\$928.00</b>
<b>Chevrolet</b>	<b>PullRite #</b>	<b>PullRite #</b>	<b>PullRite #</b>	<b>PullRite #</b>
1999-2008 2500/3500 & 1999-2005 1500 All Cab Styles, 6' Beds	n/a	3345	3340	3515
1999-2007 1500 6' Bed (except '07 New Body Style)	n/a	3345	3340	3515
2007-2008 1500 New Body Style, 6' Bed	n/a	4423	3340	n/a
2004-2007 1500 w/5'8" Bed (except 2007 new body style, added limitations on trailers over 98" wide)	3114	n/a	n/a	n/a
2007-2008 1500 w/5'8" Bed (New Body Style Only)	3117	n/a	n/a	n/a
<b>Dodge</b>				
1995-2002 (except '02 1/2 Ton)	n/a	3346	3340	3516
2003-2008 3/4 & 1 ton 2002-2007 1/2 ton (NO DRILL) (added limitations on trailers over 96" wide)	n/a	3349	n/a	3519
2006-2008 Mega Cab (added limitations on trailers over 96" wide)	n/a	3349	n/a	3519
<b>Ford</b>				
1987-1998 Super Duty	n/a	3341	3340	3511
1997-2003 F-150 (not SuperCrew)	n/a	3342	3340	3512
1999-2008 Super Duty	n/a	3343	3340	3513
2001-2003 SuperCrew F-150 (5'6" Bed)	3111	n/a	n/a	n/a
2004-2007 F-150 (6 1/2' bed)	n/a	3361	n/a	n/a
2004-2007 SuperCrew F-150 (5'6" bed) (added limitations on trailers over 90" wide)	3113	n/a	n/a	n/a
<b>Nissan</b>				
2004-2008 Titan (CrewCab limitations on trailers over 90" wide, KingCab may be ok up to 102" wide - call for information.)	3115	n/a	n/a	n/a
<b>Toyota</b>				
2001-2006 Tundra (Standard and Extra Cab)	3112	n/a	n/a	n/a
2007-2008 Tundra (Double Cab Only) 6 1/2' Bed (Universal type rails, with Custom Mounting Brackets)	n/a	n/a	4421	n/a
2007-08 Tundra (Crew Max Only 5'8" Bed Only)	3118	n/a	n/a	n/a